FOR MAINTENANCE

1. IF YOUR IRON DOES NOT HEAT. Check the electrical outlet for a defective socket or a blown fuse. You can test the outlet by plugging in a lamp. If the outlet is satisfactory, check the iron cord for visible damage.
2. IF YOUR IRON DOES NOT STEAM. Push the STEAM/DRY BUTTON on the top of the iron up and down several times. This will clear the water passage of any foreign material.
3. IF YOUR IRON SPITS OR TRAILS WATER. While steam ironing this can be easily corrected by moving the TEMPERATURE SELECTOR DIAL clockwise to slightly higher setting in the RED ZONE.

TO MAIL – TO TRAVEL – TO MOVE HOUSEHOLD GOODS

Empty the iron and allow to cool before packing. Pack carefully. The original box is not heavy enough for mailing. Therefore, use additional packing material to ensure that the iron is protected. Be sure the plug does not come into contact with the soleplate and scratch it.

HELPFUL HINTS AND TECHNIQUES

- Check garment labels for ironing instructions.
- Before ironing sort the garments according to the different heat settings they require.
- An iron heats faster than it cools. Therefore, iron fabrics that need a cool temperature setting first, then iron fabrics that require higher temperatures.
- Because there are so many different kinds of fabrics today, check the temperature of the iron on an inside seam or hem before you iron the right side of the garment. If the iron does not glide smoothly over the fabric or if the fabric changes color, stains from water, or begins to shine, adjust the TEMPERATURE SELECTOR DIAL to another temperature setting, or use a press cloth, and test the iron again. A press cloth is a lightweight cloth, such as a thin dish towel or a piece of muslin, that is placed on top of the garment when it is ironed.
- Do not touch plastic buttons with hot iron because they could melt.
- Be careful around zippers to avoid scratching the soleplate.
- For cottons and linens, iron light colors on the right side for a smooth, shiny finish; for dull finishes iron on the wrong side. Dark colors should be ironed on the wrong side to prevent marking.

INTERNATIONAL TEXTILE CARE & LABELLING CODES.

As a guide to the International Textile Care Labelling Code the following symbols are noted for your information.

Washing

Dry Cleaning

Chlorine Bleaching

Ironing

A symbol crossed out indicates that the article of clothing must not be subjected to the particular treatment.

(DO NOT BLEACH)

LIMITED WARRANTY

YOUR NEW PROCTOR-SILEX APPLIANCE IS WARRANTED FOR A PERIOD OF ONE YEAR FROM THE DATE OF PURCHASE.

THIS WARRANTY PROVIDES FOR REPAIR OR REPLACEMENT WITH A COMPARABLE APPLIANCE AT OUR OPTION, FREE OF CHARGE, IF THE APPLIANCE IS HAND CARRIED OR MAILED PREPAID TO A PROCTOR-SILEX AUTHORIZED SERVICE CENTER. YOU MUST SHOW PROOF OF DATE OF PURCHASE.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. THIS WARRANTY APPLIES IN THE UNITED STATES ONLY AND DOES NOT COVER MISUSE OR USE FOR COMMERCIAL PURPOSES. PROCTOR-SILEX AUTHORIZED SERVICE CENTERS ARE INDEPENDENT BUSINESSES (NOT OWNED OR OPERATED BY PROCTOR-SILEX). A LIST OF THE AUTHORIZED SERVICE CENTERS IS ENCLOSED WITH YOUR APPLIANCE.

FABRIC CHART

Fabrics	Dry Ironing	Steam Ironing	Instructions**
ACRYLIC Acrilan*, Creslan*, Orlon* ACETATE Acele*, Celanese*, Estron* METALLICS	A	LOW STEAM ZONE **(See Note)**	Use caution because these synthetics may melt at high temperatures. Press on wrong side while damp. Press on wrong side. Do not spray.
SUEDE			Cover ironing board with brown paper and use brown paper as press cloth.
SILK	B	LOW STEAM ZONE **(See Note)**	Press fabrics with nubby weave when dry; other fabrics when slightly damp.
NYLON Qiana*, Antron* RAYON			Press wrong side. Cool slightly before removing from board. Press on wrong side while damp.
POLYESTER Ban-lon*, Dacron*, Encron*, Fortrel*, Kodel*, Trevira*	C	LOW STEAM ZONE **(See Note)**	
PERMANENT PRESS, WASH, WEAR COTTON BLENDS, TRIACETATE Arnel*	D	LOW STEAM ZONE **(See Note)**	
WOOL, ANGORA, CASHMERE, MOHAIR	1	MEDIUM STEAM ZONE	On the wrong side, steam iron with a press cloth or dry iron with a damp press cloth. Do not press completely dry.
COTTON	2	HIGH STEAM ZONE	Steam iron lightweight cottons while dry. Dampen heavier weight cottons for steam or dry ironing. Plisse, seersucker and puckered fabrics should not be ironed or the crinkle may flatten out.
LINEN VELVET, VELOUR, CORDUROY	3	HIGH STEAM ZONE	Iron medium or heavy weight linens while slightly damp. Turn garment wrong side out. Hold iron a few inches above the garment. Use the extra blast of steam.

*Fiber manufacturer's trademark

**Check garment for specific ironing instructions. Always follow manufacturer's instructions.

Note: If Steam ironing fabrics in the **A, B, C** or **D** zone, use a press cloth and a low steam setting.

Proctor-Silex. 2209 SULPHUR SPRING RD. BALTIMORE, MD. 21227

091530 REV. A G18 Printed in U.S.A.